

UZO PLUS

Filling Instructions

- **Step One:** Open the pod up, by twisting it counterclockwise until it is fully detached. After you have taken it off, place the mouthpiece in a safe location, so it is not lost or damaged..
- **Step Two:** Fill the pod with a syringe. But if you do not have a syringe, an eye-dropper does the job as well. Syringes do more precise work and have a lesser risk of leaking products.
- **Step Three:** Place the cap back on the mouthpiece immediately (within 1.5 minutes) after filling to prevent leakage.

After Filled

- Please invert capped and pre-filled products for a minimum of 30 minutes to allow oil to cool away from the atomizer. Doing this prevents fractures from forming in the atomizer.
- After inverting the product, please invert again to stand straight up for another 30 minutes before use to allow the ceramic coil to saturate, otherwise dry burning might produce burnt flavors by using the product immediately after filling. The more viscous the oil is, the longer time it should stand.
- Storage environment temperature for capped and pre-filled products: 68 degrees F - 77 degrees F.

Additional Info

- Available in 1.0 mL & 2.0mL
- The needle's outer diameter must be $\leq 1.8\text{mm}$.
- Do not pre-heat oil higher than 122 degrees F.
- The coil begins to absorb up to around 30% of the tank size of oil. The oil volume will be visually reduce and headspace will be formed.

For any other information. Please contact
Info@ikrusher.com

Step 1



Step 2



Step 3



After Filled

